

DMX-TABLE

Brand:	Algam Lighting
Type:	MS-60
Mode:	11 channels

DMX Ch	Value	Function
1	0-255	Pan rotation
2	0-255	Tilt rotation
3	0-255	Pan & Tilt speed
4	0-255	Dimmer
5	0-255	Strobe
6	0-139	Color selection
	140-255	Automatic color change
7	0-128	Gobo selection
	129-255	Automatic gobo change
8	0-99	Prism off
	100-127	Prism on
	128-255	Prism rotation slow - fast
9	0-255	Focus adjustment
10	0-59	DMX control
	60-75	Auto program 0
	76-90	Auto program 1
	91-105	Auto program 2
	106-120	Auto program 3
	121-135	Auto program 4
	136-159	Auto program 5
	160-175	Music program 0
	176-190	Music program 1
	191-205	Music program 2
	206-220	Music program 3
	221-235	Music program 4
	236-255	Music program 5
11		Reset

DMX-TABLE

Brand:	Algam Lighting
Type:	MS-60
Mode:	13 channels

DMX Ch	Value	Function
1	0-255	Pan rotation
2	0-255	Pan rotation - Fine
3	0-255	Tilt rotation
4	0-255	Tilt rotation - Fine
5	0-255	Pan & Tilt speed
6	0-255	Dimmer
7	0-255	Strobe
8	0-139	Color selection
	140-255	Automatic color change
9	0-128	Gobo selection
	129-255	Automatic gobo change
10	0-99	Prism off
	100-127	Prism on
	128-255	Prism rotation slow - fast
11	0-255	Focus adjustment
12	0-59	DMX control
	60-75	Auto program 0
	76-90	Auto program 1
	91-105	Auto program 2
	106-120	Auto program 3
	121-135	Auto program 4
	136-159	Auto program 5
	160-175	Music program 0
	176-190	Music program 1
	191-205	Music program 2
	206-220	Music program 3
	221-235	Music program 4
	236-255	Music program 5
13		Reset