

**UDG**<sup>®</sup>  
UDGGEAR.COM

# CONTROLLER COMPATIBILITY GUIDE



EDITION  
06/2014

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p><b>U8001BL LAPTOP BACKPACK BLACK</b></p>  <p>32.5 (W) x 42 (H) x 16.5 (D) cm 12.8 x 16.5 x 6.5 inch</p>	<p><b>PIONEER DDJ-WeG02</b></p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p><b>PIONEER DJM-900SRT</b></p>  <p>40.4 (W) x 33.1 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch</p>	<p><b>PIONEER DJM-850K/S/W</b></p>  <p>32 (W) x 38 (H) x 10.8 (D) cm 12.6 x 15 x 4.25 inch</p>	<p><b>RANE SIXTY FOUR</b></p>  <p>30.5 (W) x 36.4 (H) x 10.2 (D) cm 12 x 14.3 x 4 inch</p>	<p><b>RELOOP JOCKEY 3 REMIX</b></p>  <p>42 (W) x 31.5 (H) x 6.2 (D) cm 16.5 x 12.4 x 2.4 inch</p>
<p><b>U8004BL LAPTOP BACKPACK COMPACT BLACK</b></p>  <p>33.5 (W) x 40 (H) x 15.5 (D) cm 13.2 x 15.7 x 6.1 inch</p>	<p><b>PIONEER DDJ-WeG02</b></p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p><b>PIONEER DJM-900SRT</b></p>  <p>40.4 (W) x 33.1 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch</p>	<p><b>PIONEER DJM-750K/S</b></p>  <p>32 (W) x 37.6 (H) x 10.8 (D) cm 12.6 x 14.8 x 4.25 inch</p>	<p><b>RANE SIXTY FOUR</b></p>  <p>30.5 (W) x 36.4 (H) x 10.2 (D) cm 12 x 14.3 x 4 inch</p>	<p><b>ABLETON PUSH</b></p>  <p>37 (W) x 29.3 (H) x 4.6 (D) cm 14.6 x 11.5 x 1.8 inch</p>
<p><b>U8007BL WHEELED LAPTOP BACKPACK BLACK 21"</b></p>  <p>30 (W) x 47 (H) x 10 (D) cm 11.8 x 18.5 x 3.9 inch</p>	<p><b>PIONEER DDJ-SP1</b></p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p><b>PIONEER DDJ-WeG02</b></p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p><b>PIONEER DJM-T1</b></p>  <p>26.4 (W) x 40.4 (H) x 10.9 (D) cm 10.4 x 15.9 x 4.3 inch</p>	<p><b>PIONEER DJM-4000</b></p>  <p>21.8 (W) x 30.1 (H) x 10.7 (D) cm 8.6 x 11.9 x 4.2 inch</p>	<p><b>NI TRAKTOR Z2</b></p>  <p>27 (W) x 38.8 (H) x 10.9 (D) cm 10.7 x 15.2 x 4.3 inch</p>
<p><b>U8012BL WHEELED MIDI CONTROLLER BRIEFCASE BLACK 15.6"</b></p>  <p>42 (W) x 34 (H) x 15 (D) cm 16.5 x 13.4 x 5.9 inch</p>	<p><b>PIONEER DDJ-SP1</b></p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p><b>PIONEER DDJ-WeG02</b></p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p><b>NI TRAKTOR Z2</b></p>  <p>27 (W) x 38.8 (H) x 10.9 (D) cm 10.7 x 15.2 x 4.3 inch</p>	<p><b>RANE SIXTY FOUR</b></p>  <p>30.5 (W) x 36.4 (H) x 10.2 (D) cm 12 x 14.3 x 4 inch</p>	<p><b>ABLETON PUSH</b></p>  <p>37 (W) x 29.3 (H) x 4.6 (D) cm 14.6 x 11.5 x 1.8 inch</p>
	<p><b>RELOOP RMX-80</b></p>  <p>38.2 (W) x 32 (H) x 10.8 (D) cm 15 x 12.6 x 4.3 inch</p>	<p><b>RELOOP MIXAGE IE</b></p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>	<p><b>AKAI MPC ELEMENT</b></p>  <p>28.4 (W) x 20.5 (H) x 1.7 (D) cm 11.2 x 8.1 x 0.7 inch</p>	<p><b>NUMARK MIXTRACK EDGE</b></p>  <p>27 (W) x 20.6 (H) x 1.9 (D) cm 10.6 x 8.1 x 0.7 inch</p>	<p>15.6"</p>  <p>15.6" laptop and small gears</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U8301BL CONTROLLER HARDCASE MEDIUM BLACK</p>  <p><b>NEW</b></p> <p>47 (W) x 34 (H) x 8.4 (D) cm 18.5 x 13.4 x 3.3 inch</p>	<p>PIONEER DDJ-WeG02</p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p>NI MASCHINE STUDIO</p>  <p>43.2 (W) x 35 (H) x 5.9 (D) cm 17 x 13.8 x 2.3 inch</p>	<p>NI TRAKTOR S2 MK2</p>  <p>43.8 (W) x 30.8 (H) x 6.7 (D) cm 17.24 x 12.1 x 2.6 inch</p>	<p>RELOOP JOCKEY 3 REMIX</p>  <p>42 (W) x 31.5 (H) x 6.2 (D) cm 16.5 x 12.4 x 2.4 inch</p>	<p>DENON DN-MC3000</p>  <p>46 (W) x 25.5 (H) x 6 (D) cm 18.1 x 10 x 2.4 inch</p>
<p>U8302BL CONTROLLER HARDCASE LARGE BLACK</p>  <p><b>NEW</b></p> <p>59.3 (W) x 35.2 (H) x 9 (D) cm 23.3 x 13.9 x 3.5 inch</p>	<p>PIONEER DDJ-SR</p>  <p>55.4 (W) x 31.9 (H) x 6.5 (D) cm 21.8 x 12.5 x 2.6 inch</p>	<p>PIONEER DDJ-ERGO</p>  <p>55.8 (W) x 28 (H) x 10.2 (D) cm 21.8 x 11 x 4 inch</p>	<p>NUMARK MIXTRACK QUAD</p>  <p>47.6 (W) x 27.9 (H) x 5.1 (D) cm 18.7 x 11 x 2 inch</p>	<p>NUMARK N4</p>  <p>57.2 (W) x 30.5 (H) x 6.1 (D) cm 22.5 x 12 x 2.4 inch</p>	<p>AKAI MPC RENAISSANCE</p>  <p>50 (W) x 32.3 (H) x 7 (D) cm 19.6 x 12.7 x 2.8 inch</p>
<p>U8303BL CONTROLLER HARDCASE EXTRA LARGE BLACK</p>  <p><b>NEW</b></p> <p>71.5 (W) x 41.5 (H) x 10 (D) cm 28.2 x 16.3 x 3.9 inch</p>	<p>PIONEER DDJ-SX</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER XDJ-R1</p>  <p>62.3 (W) x 30.8 (H) x 10.8 (D) cm 24.5 x 12.1 x 4.2 inch</p>	<p>PIONEER XDJ-AERO</p>  <p>62.3 (W) x 28.9 (H) x 6.5 (D) cm 24.5 x 11.3 x 2.5 inch</p>	<p>PIONEER DDJ-S1</p>  <p>68.1 (W) x 31.8 (H) x 9.6 (D) cm 26.8 x 12.5 x 3.8 inch</p>	<p>PIONEER DDJ-T1</p>  <p>68.1 (W) x 31.8 (H) x 9.6 (D) cm 26.8 x 12.5 x 3.8 inch</p>
<p>U7001BL MIDI CONTROLLER FLIGHTBAG MEDIUM</p>  <p><b>NEW</b></p> <p>53 (W) x 34 (H) x 9 (D) cm 20.8 x 13.4 x 3.5 inch</p>	<p>PIONEER DDJ-SB</p>  <p>48.7 (W) x 27.1 (H) x 5.9 (D) cm 19.2 x 10.7 x 2.3 inch</p>	<p>RELOOP BEATMIX 2</p>  <p><b>NEW</b></p> <p>49.2 (W) x 31.7 (H) x 3.5 (D) cm 19.3 x 12.5 x 1.4 inch</p>	<p>RELOOP BEATPAD</p>  <p>46 (W) x 32.5 (H) x 4.2 (D) cm 18.1 x 12.8 x 1.65 inch</p>	<p>NUMARK MIXTRACK QUAD</p>  <p>47.6 (W) x 27.9 (H) x 5.1 (D) cm 18.7 x 11 x 2 inch</p>	<p>NUMARK MIXTRACK PRO II</p>  <p>46.5 (W) x 26.4 (H) x 5.1 (D) cm 18.3 x 10.4 x 2 inch</p>
	<p>VESTAX VCI-400DJ</p>  <p>45.7 (W) x 32.8 (H) x 6.1 (D) cm 18 x 12.9 x 2.4 inch</p>	<p>AKAI MPC RENAISSANCE</p>  <p>50 (W) x 32.3 (H) x 7 (D) cm 19.6 x 12.7 x 2.8 inch</p>	<p>NI TRAKTOR S2 MK2</p>  <p>43.8 (W) x 30.8 (H) x 6.7 (D) cm 17.24 x 12.1 x 2.6 inch</p>	<p>NI TRAKTOR S4 MK2</p>  <p>50 (W) x 33.8 (H) x 7.2 (D) cm 19.7 x 13.3 x 2.8 inch</p>	 <p>15.4" laptop and small gears</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U7002BL MIDI CONTROLLER FLIGHTBAG LARGE</p>  <p>70 (W) x 40 (H) x 11 (D) cm 27.6 x 15.7 x 4.3 inch</p>	<p>PIONEER DDJ-SR</p>  <p>55.4 (W) x 31.9 (H) x 6.5 (D) cm 21.8 x 12.5 x 2.6 inch</p>	<p>PIONEER XDJ-R1</p>  <p>62.3 (W) x 30.8 (H) x 10.8 (D) cm 24.5 x 12.1 x 4.2 inch</p>	<p>PIONEER DDJ-SX</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER DDJ-ERGO</p>  <p>55.8 (W) x 28 (H) x 10.2 (D) cm 21.8 x 11 x 4 inch</p>	<p>PIONEER XDJ-AERO</p>  <p>62.3 (W) x 28.9 (H) x 6.5 (D) cm 24.5 x 11.3 x 2.5 inch</p>
<p>U7101BL MIDI CONTROLLER SLEEVE MEDIUM</p>  <p>53 (W) x 34 (H) x 9 (D) cm 20.8 x 13.4 x 3.5 inch</p>	<p>PIONEER DDJ-SB</p>  <p>48.7 (W) x 27.1 (H) x 5.9 (D) cm 19.2 x 10.7 x 2.3 inch</p>	<p>RELOOP BEATMIX 2</p>  <p>49.2 (W) x 31.7 (H) x 3.5 (D) cm 19.3 x 12.5 x 1.4 inch</p>	<p>RELOOP BEATPAD</p>  <p>46 (W) x 32.5 (H) x 4.2 (D) cm 18.1 x 12.8 x 1.65 inch</p>	<p>NUMARK MIXTRACK QUAD</p>  <p>47.6 (W) x 27.9 (H) x 5.1 (D) cm 18.7 x 11 x 2 inch</p>	<p>NUMARK MIXTRACK PRO II</p>  <p>46.5 (W) x 26.4 (H) x 5.1 (D) cm 18.3 x 10.4 x 2 inch</p>
<p>U7102BL MIDI CONTROLLER SLEEVE LARGE</p>  <p>70 (W) x 40 (H) x 11 (D) cm 27.6 x 15.7 x 4.3 inch</p>	<p>PIONEER DDJ-SR</p>  <p>55.4 (W) x 31.9 (H) x 6.5 (D) cm 21.8 x 12.5 x 2.6 inch</p>	<p>PIONEER XDJ-R1</p>  <p>62.3 (W) x 30.8 (H) x 10.8 (D) cm 24.5 x 12.1 x 4.2 inch</p>	<p>PIONEER DDJ-SX</p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p>PIONEER DDJ-ERGO</p>  <p>55.8 (W) x 28 (H) x 10.2 (D) cm 21.8 x 11 x 4 inch</p>	<p>PIONEER XDJ-AERO</p>  <p>62.3 (W) x 28.9 (H) x 6.5 (D) cm 24.5 x 11.3 x 2.5 inch</p>
<p>U9022BL/OR PRODUCER BAG LARGE BLACK, ORANGE INSIDE</p>  <p>32 (W) x 46.5 (H) x 15 (D) cm 12.6 x 18.3 x 5.9 inch</p>	<p>PIONEER DJM-900SRT</p>  <p>40.4 (W) x 33.1 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch</p>	<p>PIONEER DJM-T1</p>  <p>26.4 (W) x 40.4 (H) x 10.9 (D) cm 10.4 x 15.9 x 4.3 inch</p>	<p>RANE SIXTY FOUR</p>  <p>30.5 (W) x 36.4 (H) x 10.2 (D) cm 12 x 14.3 x 4 inch</p>	<p>NI TRAKTOR Z2</p>  <p>27 (W) x 38.8 (H) x 10.9 (D) cm 10.7 x 15.2 x 4.3 inch</p>	<p>RELOOP RMX-80</p>  <p>38.2 (W) x 32 (H) x 10.8 (D) cm 15 x 12.6 x 4.3 inch</p>
	<p>RELOOP JOCKEY 3 REMIX</p>  <p>42 (W) x 31.5 (H) x 6.2 (D) cm 16.5 x 12.4 x 2.4 inch</p>	<p>NUMARK MIXTRACK PRO II</p>  <p>46.5 (W) x 26.4 (H) x 5.1 (D) cm 18.3 x 10.4 x 2 inch</p>	<p>DENON DN-X1700</p>  <p>35.7 (W) x 32 (H) x 9 (D) cm 14.1 x 12.6 x 3.5 inch</p>	<p>HERCULES DJ CONTROL AIR+</p>  <p>45.5 (W) x 26 (H) x 8 (D) cm 17.9 x 10.2 x 3.1 inch</p>	<p>17"</p>  <p>17" laptop and small gears</p>
					<p>15.4"</p>  <p>15.4" laptop and small gears</p>
					<p>17"</p>  <p>17" laptop and small gears</p>
					<p>18.4"</p>  <p>18.4" laptop and small gears</p>








UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9023BL/OR PRODUCER BAG SMALL BLACK, ORANGE INSIDE</p>  <p>26 (W) x 40 (H) x 15 (D) cm 10.2 x 15.7 x 5.9 inch</p>	<p>PIONEER DDJ-WeG02</p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p>RELOOP MIXAGE IE</p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>	<p>NUMARK MIXTRACK EDGE</p>  <p>27 (W) x 20.6 (H) x 1.9 (D) cm 10.6 x 8.1 x 0.7 inch</p>	<p>HERCULES DJCONSULE 4-MX</p>  <p>40 (W) x 25 (H) x 1.9 (D) cm 15.7 x 9.8 x 0.7 inch</p>	<p>GEMINI FIRSTMIX PRO</p>  <p>37 (W) x 23 (H) x 6.1 (D) cm 14.6 x 9.1 x 2.4 inch</p>
<p>U9101BL/OR DIGI BACKPACK BLACK, ORANGE INSIDE</p>  <p>30 (W) x 42 (H) x 13 (D) cm 11.8 x 16.5 x 5.1 inch</p>	<p>PIONEER DDJ-SP1</p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p>PIONEER DDJ-WeG02</p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p>AKAI MPC ELEMENT</p>  <p>28.4 (W) x 20.5 (H) x 1.7 (D) cm 11.2 x 8.1 x 0.7 inch</p>	<p>ABLETON PUSH</p>  <p>37 (W) x 29.3 (H) x 4.6 (D) cm 14.6 x 11.5 x 1.8 inch</p>	<p>RELOOP MIXAGE IE</p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>
<p>U9102BL/OR BACKPACK BLACK, ORANGE INSIDE</p>  <p>33 (W) x 40 (H) x 14 (D) cm 13 x 15.7 x 5.5 inch</p>	<p>PIONEER DDJ-SP1</p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p>PIONEER DDJ-WeG02</p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p>AKAI MPC ELEMENT</p>  <p>28.4 (W) x 20.5 (H) x 1.7 (D) cm 11.2 x 8.1 x 0.7 inch</p>	<p>ABLETON PUSH</p>  <p>37 (W) x 29.3 (H) x 4.6 (D) cm 14.6 x 11.5 x 1.8 inch</p>	<p>VESTAX SPIN 2</p>  <p>35.4 (W) x 25 (H) x 4.7 (D) cm 13.9 x 9.8 x 1.8 inch</p>
<p>U9103BL/OR MIDI CONTROLLER BACKPACK SMALL BLACK/ORANGE</p>  <p>50 (W) x 35.5 (H) x 8 (D) cm 19.7 x 13.2 x 3.1 inch</p>	<p>PIONEER DDJ-SB</p>  <p>48.7 (W) x 27.1 (H) x 5.9 (D) cm 19.2 x 10.7 x 2.3 inch</p>	<p>RELOOP BEATMIX 2 <b>NEW</b></p>  <p>49.2 (W) x 31.7 (H) x 3.5 (D) cm 19.3 x 12.5 x 1.4 inch</p>	<p>RELOOP BEATPAD</p>  <p>46 (W) x 32.5 (H) x 4.2 (D) cm 18.1 x 12.8 x 1.65 inch</p>	<p>NUMARK MIXTRACK QUAD</p>  <p>47.6 (W) x 27.9 (H) x 5.1 (D) cm 18.7 x 11 x 2 inch</p>	<p>NUMARK MIXTRACK PRO II</p>  <p>46.5 (W) x 26.4 (H) x 5.1 (D) cm 18.3 x 10.4 x 2 inch</p>
<p>VESTAX VCI-400DJ</p>  <p>45.7 (W) x 32.8 (H) x 6.1 (D) cm 18 x 12.9 x 2.4 inch</p>	<p>AKAI MPC RENAISSANCE</p>  <p>50 (W) x 32.3 (H) x 7 (D) cm 19.6 x 12.7 x 2.8 inch</p>	<p>NI TRAKTOR S2 MK2</p>  <p>43.8 (W) x 30.8 (H) x 6.7 (D) cm 17.24 x 12.1 x 2.6 inch</p>	<p>NI TRAKTOR S4 MK2</p>  <p>50 (W) x 33.8 (H) x 7.2 (D) cm 19.7 x 13.3 x 2.8 inch</p>	<p>15.4" laptop and small gears</p> 	







UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p><b>U9104BL/OR</b> MIDI CONTROLLER BACKPACK LARGE BLACK/ORANGE</p>  <p>68.5 (W) x 36 (H) x 13 (D) cm 26.9 x 14.1 x 5.1 inch</p>	<p><b>PIONEER DDJ-SR</b></p>  <p>55.4 (W) x 31.9 (H) x 6.5 (D) cm 21.8 x 12.5 x 2.6 inch</p>	<p><b>PIONEER XDJ-R1</b></p>  <p>62.3 (W) x 30.8 (H) x 10.8 (D) cm 24.5 x 12.1 x 4.2 inch</p>	<p><b>PIONEER DDJ-SX</b></p>  <p>66.4 (W) x 35.7 (H) x 7 (D) cm 26.1 x 14 x 2.7 inch</p>	<p><b>PIONEER DDJ-ERGO</b></p>  <p>55.8 (W) x 28 (H) x 10.2 (D) cm 21.8 x 11 x 4 inch</p>	<p><b>PIONEER XDJ-AERO</b></p>  <p>62.3 (W) x 28.9 (H) x 6.5 (D) cm 24.5 x 11.3 x 2.5 inch</p>
<p><b>U9011</b> MIDI CONTROLLER SLINGBAG SMALL BLACK/ORANGE</p>  <p>44 (W) x 33 (H) x 7 (D) cm 17.5 x 13 x 2.8 inch</p>	<p><b>NI TRAKTOR S2 MK2</b></p>  <p>43.8 (W) x 30.8 (H) x 6.7 (D) cm 17.24 x 12.1 x 2.6 inch</p>	<p><b>PIONEER DDJ-SP1</b></p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p><b>PIONEER DDJ-WeGO2</b></p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p><b>ABLETON PUSH</b></p>  <p>37 (W) x 29.3 (H) x 4.6 (D) cm 14.6 x 11.5 x 1.8 inch</p>	<p><b>NUMARK iDJ LIVE II</b></p>  <p>41.9 (W) x 19.6 (H) x 4.8 (D) cm 16.5 x 7.7 x 1.9 inch</p>
<p><b>U9012</b> MIDI CONTROLLER SLINGBAG MEDIUM BLACK/ORANGE</p>  <p>47.5 (W) x 36 (H) x 9 (D) cm 18.7 x 14.2 x 3.5 inch</p>	<p><b>NI MASCHINE STUDIO</b></p>  <p>43.2 (W) x 35 (H) x 5.9 (D) cm 17 x 13.8 x 2.3 inch</p>	<p><b>NI TRAKTOR S2 MK2</b></p>  <p>43.8 (W) x 30.8 (H) x 6.7 (D) cm 17.24 x 12.1 x 2.6 inch</p>	<p><b>RELOOP BEATPAD</b></p>  <p>46 (W) x 32.5 (H) x 4.2 (D) cm 18.1 x 12.8 x 1.65 inch</p>	<p><b>RELOOP JOCKEY 3 REMIX</b></p>  <p>42 (W) x 31.5 (H) x 6.2 (D) cm 16.5 x 12.4 x 2.4 inch</p>	<p><b>RELOOP MIXAGE IE</b></p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>
<p><b>U9013</b> MIDI CONTROLLER SLINGBAG LARGE BLACK/ORANGE</p>  <p>50 (W) x 34 (H) x 7 (D) cm 19.7 x 13.4 x 2.7 inch</p>	<p><b>PIONEER DDJ-SB</b></p>  <p>48.7 (W) x 27.1 (H) x 5.9 (D) cm 19.2 x 10.7 x 2.3 inch</p>	<p><b>NUMARK MIXTRACK QUAD</b></p>  <p>47.6 (W) x 27.9 (H) x 5.1 (D) cm 18.7 x 11 x 2 inch</p>	<p><b>NUMARK MIXTRACK PRO II</b></p>  <p>46.5 (W) x 26.4 (H) x 5.1 (D) cm 18.3 x 10.4 x 2 inch</p>	<p><b>RELOOP BEATPAD</b></p>  <p>46 (W) x 32.5 (H) x 4.2 (D) cm 18.1 x 12.8 x 1.65 inch</p>	<p><b>RELOOP JOCKEY 3 REMIX</b></p>  <p>42 (W) x 31.5 (H) x 6.2 (D) cm 16.5 x 12.4 x 2.4 inch</p>
	<p><b>NI TRAKTOR S4 MK2</b></p>  <p>50 (W) x 33.8 (H) x 7.2 (D) cm 19.7 x 13.3 x 2.8 inch</p>	<p><b>AKAI MPC RENAISSANCE</b></p>  <p>50 (W) x 32.3 (H) x 7 (D) cm 19.6 x 12.7 x 2.8 inch</p>	<p><b>VESTAX VCI-400DJ</b></p>  <p>45.7 (W) x 32.8 (H) x 6.1 (D) cm 18 x 12.9 x 2.4 inch</p>	<p><b>AMERICAN AUDIO VMS 4.1 TRAKTOR</b></p>  <p>48.2 (W) x 32.5 (H) x 4 (D) cm 19 x 12.8 x 1.6 inch</p>	<p>20"</p>  <p>20" laptop and small gears</p>

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9470BL/OR /U9446/U9448 COURIER BAG DELUXE</p>  <p>35.5 (W) x 33 (D) x 9 (D) cm 14 x 13 x 3.7 inch</p>	<p>PIONEER DDJ-SP1</p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p>NUMARK MIXTRACK EDGE</p>  <p>27 (W) x 20.6 (H) x 1.9 (D) cm 10.6 x 8.1 x 0.7 inch</p>	<p>VESTAX SPIN 2</p>  <p>35.4 (W) x 25 (H) x 4.7 (D) cm 13.9 x 9.8 x 1.8 inch</p>	<p>AKAI MPC ELEMENT</p>  <p>28.4 (W) x 20.5 (H) x 1.7 (D) cm 11.2 x 8.1 x 0.7 inch</p>	<p>AKAI MPC 500</p>  <p>26.6 (W) x 17.5 (H) x 4.4 (D) cm 10.47 x 6.89 x 1.73 inch</p>
<p>U9490BL/OR COURIER BAG DELUXE 17" BLACK, ORANGE INSIDE</p>  <p>43 (W) x 36 (H) x 9 (D) cm 16.9 x 14.2 x 3.5 inch</p>	<p>PIONEER DDJ-WeGO2</p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p>RELOOP JOCKEY 3 REMIX</p>  <p>42 (W) x 31.5 (H) x 6.2 (D) cm 16.5 x 12.4 x 2.4 inch</p>	<p>RELOOP MIXAGE IE</p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>	<p>AKAI MPC ELEMENT</p>  <p>28.4 (W) x 20.5 (H) x 1.7 (D) cm 11.2 x 8.1 x 0.7 inch</p>	<p>AKAI APC 40</p>  <p>42.9 (W) x 33.4 (H) x 6.7 cm 16.9 x 13.2 x 2.6 inch</p>
<p>U9495BL COURIER BAG DELUXE NOVATION TWITCH BLACK</p>  <p>Officially Licensed Product <b>novation</b><sup>®</sup></p> <p>39 (W) x 34 (H) x 14.5 (D) cm 15.4 x 13.4 x 5.7 inch</p>	<p>PIONEER DDJ-WeGO2</p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p>AKAI MPC ELEMENT</p>  <p>28.4 (W) x 20.5 (H) x 1.7 (D) cm 11.2 x 8.1 x 0.7 inch</p>	<p>RELOOP MIXAGE IE</p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>	<p>GEMINI FIRSTMIX PRO</p>  <p>37 (W) x 23 (H) x 6.1 (D) cm 14.6 x 9.1 x 2.4 inch</p>	<p>NOVATION TWITCH</p>  <p>35 (W) x 27.5 (H) x 6.5 (D) cm 13.8 x 10.8 x 2.5 inch</p>
<p>U9120BL CD PLAYER/MIXER BAG SMALL BLACK</p>  <p>21.5 (W) x 30.5 (H) x 11.5 (D) cm 8.5 x 12 x 4.5 inch</p>	<p>PIONEER CDJ-350</p>  <p>22 (W) x 28.9 (H) x 10.7 (D) cm 8.7 x 11.4 x 4.2 inch</p>	<p>PIONEER CDJ-400</p>  <p>21.8 (W) x 29.6 (H) x 10.7 (D) cm 8.6 x 11.7 x 4.2 inch</p>	<p>PIONEER CDJ-200</p>  <p>21.6 (W) x 29.2 (H) x 10.7 (D) cm 8.5 x 11.5 x 4.2 inch</p>	<p>PIONEER DJM-350/350W</p>  <p>21.8 (W) x 30.1 (H) x 10.7 (D) cm 8.6 x 11.9 x 4.2 inch</p>	<p>PIONEER DJM-400</p>  <p>22.3 (W) x 30.5 (H) x 10.7 (D) cm 8.8 x 12 x 4.2 inch</p>
	<p>PIONEER DJM-4000</p>  <p>21.8 (W) x 30.1 (H) x 10.7 (D) cm 8.6 x 11.9 x 4.2 inch</p>	<p>NUMARK M1</p>  <p>19.7 (W) x 26.75 (H) x 10 (D) cm 7.7 x 10.5 x 3.9 inch</p>	<p>NUMARK DM950</p>  <p>19.7 (W) x 26.75 (H) x 10 (D) cm 7.7 x 10.5 x 3.9 inch</p>		

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p><b>U9121BL</b> CD PLAYER/MIXER BAG LARGE BLACK</p>  <p>32.5 (W) x 41 (H) x 12.5 (D) cm 12.8 x 16.1 x 4.9 inch</p>	<p><b>RANE SIXTY FOUR</b></p>  <p>30.5 (W) x 36.4 (H) x 10.2 (D) cm 12 x 14.3 x 4 inch</p>	<p><b>RANE SIXTY EIGHT</b></p>  <p>36.4 (W) x 30.5 (H) x 10.2 (D) cm 14.3 x 12 x 4 inch</p>	<p><b>RANE SIXTY TWO/TWO Z</b></p>  <p>36.2 (W) x 26.7 (H) x 10.2 (D) cm 14.2 x 10.5 x 4 inch</p>	<p><b>RELOOP RMX-80</b></p>  <p>38.2 (W) x 32 (H) x 10.8 (D) cm 15 x 12.6 x 4.3 inch</p>	<p><b>NI TRAKTOR Z2</b></p>  <p>27 (W) x 38.8 (H) x 10.9 (D) cm 10.7 x 15.2 x 4.3 inch</p>
<p><b>U9018</b> PIONEER CD PLAYER/MIXER BAG SMALL</p>  <p>21.5 (W) x 30.5 (H) x 11.5 (D) cm 8.5 x 12 x 4.5 inch</p>	<p><b>PIONEER CDJ-350</b></p>  <p>22 (W) x 28.9 (H) x 10.7 (D) cm 8.7 x 11.4 x 4.2 inch</p>	<p><b>PIONEER CDJ-400</b></p>  <p>21.8 (W) x 29.6 (H) x 10.7 (D) cm 8.6 x 11.7 x 4.2 inch</p>	<p><b>PIONEER CDJ-200</b></p>  <p>21.6 (W) x 29.2 (H) x 10.7 (D) cm 8.5 x 11.5 x 4.2 inch</p>	<p><b>PIONEER DJM-350/350W</b></p>  <p>21.8 (W) x 30.1 (H) x 10.7 (D) cm 8.6 x 11.9 x 4.2 inch</p>	<p><b>PIONEER DJM-400</b></p>  <p>22.3 (W) x 30.5 (H) x 10.7 (D) cm 8.8 x 12 x 4.2 inch</p>
<p><b>U9017</b> PIONEER CD PLAYER/MIXER BAG LARGE</p>  <p>32.5 (W) x 41 (H) x 12.5 (D) cm 12.8 x 16.1 x 4.9 inch</p>	<p><b>PIONEER DJM-900SRT</b></p>  <p>40.4 (W) x 33.1 (H) x 10.8 (D) cm 15.9 x 13 x 4.3 inch</p>	<p><b>PIONEER DJM-900 NEXUS</b></p>  <p>33 (W) x 41 (H) x 10.7 (D) cm 13 x 16.1 x 4.2 inch</p>	<p><b>PIONEER DJM-850K/S/W</b></p>  <p>32 (W) x 38 (H) x 10.8 (D) cm 12.6 x 15 x 4.25 inch</p>	<p><b>PIONEER DJM-800</b></p>  <p>32 (W) x 38.1 (H) x 11 (D) cm 12.6 x 15 x 4.3 inch</p>	<p><b>PIONEER DJM-T1</b></p>  <p>26.4 (W) x 40.4 (H) x 10.9 (D) cm 10.4 x 15.9 x 4.3 inch</p>
<p><b>U9880BL/OR</b> DIGI TROLLEY TO GO BLACK, ORANGE INSIDE</p>  <p>31 (W) x 39 (H) x 19 (D) cm 12.2 x 15.4 x 7.5 inch</p>	<p><b>PIONEER DDJ-SP1</b></p>  <p>32.8 (W) x 17.9 (H) x 4.8 (D) cm 12.9 x 7.1 x 1.9 inch</p>	<p><b>PIONEER DDJ-WeGO2</b></p>  <p>38 (W) x 20.8 (H) x 6.5 (D) cm 14.9 x 8.2 x 2.5 inch</p>	<p><b>RANE SIXTY FOUR</b></p>  <p>30.5 (W) x 36.4 (H) x 10.2 (D) cm 12 x 14.3 x 4 inch</p>	<p><b>ABLETON PUSH</b></p>  <p>37 (W) x 29.3 (H) x 4.6 (D) cm 14.6 x 11.5 x 1.8 inch</p>	<p><b>NI TRAKTOR Z2</b></p>  <p>27 (W) x 38.8 (H) x 10.9 (D) cm 10.7 x 15.2 x 4.3 inch</p>
<p><b>RELOOP MIXAGE IE</b></p>  <p>37 (W) x 25.8 (H) x 4.4 (D) cm 14.6 x 10.1 x 1.7 inch</p>	<p><b>GEMINI FIRSTMIX PRO</b></p>  <p>37 (W) x 23 (H) x 6.1 (D) cm 14.6 x 9.1 x 2.4 inch</p>	<p><b>VESTAX SPIN 2</b></p>  <p>35.4 (W) x 25 (H) x 4.7 (D) cm 13.9 x 9.8 x 1.8 inch</p>	<p><b>NOVATION TWITCH</b></p>  <p>35 (W) x 27.5 (H) x 6.5 (D) cm 13.8 x 10.8 x 2.5 inch</p>	 <p>15.4"</p> <p>15.4" laptop and small gears</p>	



UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9981BL/OR SLINGBAG TROLLEY DELUXE BLACK, ORANGE INSIDE</p>  <p>33 (W) x 33 (H) x 20 (D) cm 13 x 13 x 7.9 inch</p>	<p>60 RECORDS</p>  <p>or</p> <p>50 12" CD SLEEVE</p> 	<p>1 CD WALLET 280</p>  <p>or</p> <p>2 CD WALLET 128</p> 	<p>AUDIO INTERFACE Rane SL3/SL4</p>  <p>or</p> <p>NI Audio 6/ Komplete Audio 6</p> 	<p>FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 
<p>U9679BL/OR SLINGBAG TROLLEY SET DELUXE BLACK, ORANGE INSIDE</p>  <p>Trolley 31.5 (W) x 32 (H) x 20 (D) cm 12.4 x 12.6 x 7.9 inch SlingBag 33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch</p>	<p>110 RECORDS</p>  <p>or</p> <p>90 12" CD SLEEVE</p> 	<p>2 CD WALLET 280</p>  <p>or</p> <p>4 CD WALLET 128</p> 	<p>AUDIO INTERFACE Rane SL3/SL4</p>  <p>or</p> <p>NI Audio 6/ Komplete Audio 6</p> 	<p>FOLDABLE AND NON-FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 
<p>U9630/U9632/U9633/ U9634/U9635 SLINGBAG</p>  <p>33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch</p>	<p>50 RECORDS</p>  <p>or</p> <p>40 12" CD SLEEVE</p> 	<p>AUDIO INTERFACE Rane SL3</p>  <p>or</p> <p>NI-AUDIO 6</p> 	<p>FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 	
<p>U9870 TROLLEY TO GO BLACK</p>  <p>33 (W) x 33 (H) x 16 (D) cm 13 x 13 x 6.3 inch</p>	<p>50 RECORDS</p>  <p>or</p> <p>40 12" CD SLEEVE</p> 	<p>1 CD WALLET 280</p>  <p>or</p> <p>2 CD WALLET 128</p> 	<p>AUDIO INTERFACE Rane SL3</p>  <p>or</p> <p>NI-AUDIO 6</p> 	<p>FOLDABLE DJ HEADPHONE</p> 	<p>CABLES</p> 

UDG PRODUCT (INNER DIMENSION)	CONTROLLER (OUTER DIMENSION)				
<p>U9419/U9420/U9450 COURIER BAG</p>  <p>37.5 (W) x 30 (H) x 13 (D) cm 14.8 x 11.8 x 5.1 inch</p>	<p>40 RECORDS</p> 	<p>AUDIO INTERFACE Rane SL3/SL4</p>  <p>or</p> <p>NI Audio 6/ Komplete Audio 6</p> 	<p>CABLES</p> 		
<p>U9500 STARTER BAG BLACK/WHITE LOGO</p>  <p>32.5 (W) x 33 (H) x 17.5 (D) cm 12.8 x 13 x 6.9 inch</p>	<p>50 RECORDS</p> 